LAMP

スプリングステー S-AT PAT.P 取扱説明書

このたびは弊社製品をお買い上げいただき、誠にありがとうございます。 取り付け前に本説明書をよくお読みのうえ、正しく施工いただくようお願いいたします。 誤った取り付けは、思わぬケガをする恐れがありますので、おやめください。 取り付け後はお使いになられる方に本説明書を渡し、いつでも読めるよう保管してください。

- 本製品は上蓋に取り付けて、扉を軽く操作するためのリフトアシスト金具です。
 本来の使用目的とは異なる使用方法や、使用範囲外の扉に取り付けたことが原因による故障、ケガなどの事故につきましては、その責任を一切負いかねますのでご了承ください。
 本説明書の製品内容は、部品としての品質範囲です。本製品を使用した最終製品の機能・性能・安全性を保証するものではありません。
 製品については万全を期しておりますが、万一不良品があった場合、ご購入先へお問い合わせください。
 保証期間は、弊社出荷日より1年間とさせていただき、良品との交換をもって責任の範囲とさせていただきます。
 製品改良などにより、予告なく寸法、材料などの仕様変更を行う場合があります。念のため現品にてご確認ください。
 汚れがひどい場合は、中性洗剤を水で薄めてふきとってください。
 アルコールやシンナーなど揮発性のものは表面の仕上げを使めるので、使用しないでください。

アルコールやシンナーなど揮発性のものは表面の仕上げを傷めるので、使用しないでください。

以下の注意事項を守らないと、思わぬケガをしたり、周辺の家財に損害を与えたりする恐れがあります。

! 誤った寸法で取り付けると、扉が閉じないなど正しく機能しないだけでなく、本製品や丁番が破損する原因となります。! キャビネットおよび扉の設計の際、本製品の取付位置は指定寸法、水平、垂直度を必ずお守りください。! 本製品の側板および扉への取り付けは、垂直度を確実にお守りください。! 扉を開ききった状態からさらに開いたり、必要以上の力で扉を閉めるなど、無理な扉の開閉は絶対におやめください。 む! 本製品の使用温度範囲は0°~40°です。使用温度範囲外でのご使用はおやめください。! 本製品の分解、改造は決して行わないでください。

無理な扉の開閉は絶対におやめください。故障の原因になります。

使用扉の大きさ

■1個使いのとき(軸トルク)

機種 S-ATO1(S): $\frac{\pi}{2}$ × 扉質量(kg) × 9.8 = 6.1 ~ 8.8N·m (62 ~ 90kgf·cm)

S-ATO2(S) : $\frac{\overline{m}$ 高さ(m)}{2} \times 扉質量(kg) \times 9.8 = 8.8 \sim 11.8N·m (90 \sim 120kgf·cm)

重心は扉の中央部とします。2個使いのとき、軸トルクは2倍となります。

製品内容

■ 座金:1個



S-ATSの場合

■Mt.P:1個


9

取付ねじは別途ご用意ください。 推奨ねじ:十字穴付きトラスねじM4(板金用) 十字穴付きトラスタッピンねじ 4.0×16(木工用)


■本体ユニット:1個 ■十字穴付きトラスねじ:1本 (M4×6)

取付寸法図

S-ATO1、O2(側板付)取付寸法図



S-ATO1S、O2S(背板付)取付寸法図




扉を閉じる際に 扉を困しる。 座金が側板に 接触しないこ 確認してください。


軸丁番以外を使用する場合は、弊社担当者までお問い合わせください。

取付手順


S-ATO1、O2(側板付)取付手順




S-ATO1S、O2S(背板付)取付手順



注意





末永くお使いいただくため、取付ねじの増し締めなど定期的な点検をお願いいたします。

本製品に関するご質問・ご相談は、お買い求めいただいた販売店、または下記の窓口にお願いいたします。

アーキテクトサポート室 電話番号 03(3864)1122 受付時間 月~金 9:00~17:30 (年末·年始·夏季休暇等は除く)

> FAX 03(3863)6875 E-mail: support@sugatsune.co.jp 東京都千代田区岩本町2-5-10 〒101-0032

建 築 金 物・家 具 金 物・機 構 部 品

ISO 9001(JSAQ384) · ISO14001(JSAE597) 審査登録 ホームページ http://www.sugatsune.co.jp/ 新製品の情報、会社情報など最新情報を提供しております。 2009 11 PRINTED IN JAPAN 0455-1



SPRING LID STAY S-AT PAT.P Installation Manual

Please carefully read and follow the following instructions for proper installation of the S-AT spring lid stay

The S-AT is a stay designed to assist the lifting of lid as described below. Sugatsune declines any responsability for incident or injury caused by use others than originally intended for.
Sugatsune liability is limited to the stay. It does in no way extend to the entire final assembly.

The utmost care was taken during the production of this stay. Should you, however, find any defect, please immediately contact your local retailer for replacement.

The warranty period is one year after shipment date. Sugatsune's liability shall be limited to replacement of the product and will in no case extend to the assembly as a whole.

Strictly follow lid sizes and weight as described below.

! Operation temperature range is 0°C ~40°C
! S-AT should be installed in a vertical position. Biased installation may damage the stay.

! Do not apply excessive force when opening or closing the lid. ! Never attempt to modify or dissable the S-AT.

Applicable Lid Weight and Size

· The lid should be designed such that its torque moment is within the following range:

S-AT01(S): 62-90 kg·cm

S-AT02(S): 90-120 kg·cm

The range above is shown when using one stay. When using two stays, simply double the value.


Lid torque moment is calculated as follows: [Lid height (mmm) / 2] x [Lid weight (kg)]


Parts List

■Arm bracket : 1 pcs S-AT S-ATS or ■Body bracket: 1 pcs 9 ■ Cross recessed truss screw ■ Main body : 1 pcs (M4x6):1 pcs

Installation screws are not provided. The following screw type is recommended: Wood: cross recessed truss tapping screw Metal sheet: cross recessed truss screw M4

Installation Dimensions









! When clsoing the lid, make sure that the arm bracket does not touch the side board. ! If you do not use a single axis hinge, please contact your local reseller for technical advice.

Installation Procedure


S-AT01, S-AT02 (Side board installation)




S-AT01S, S-AT02S (Back board installation)









Please make sure to regularly tighten all installation screws.

SUGATSUNE KOGYO CO..LTD.

Phone: +81 (0)3 3866 2260 Fax: +81 (0)3 3866 4447 E-mail: export@sugatsune.co.jp Website: www.sugatsune-intl.com

SUGATSUNE KOGYO (UK) LTD.

Phone: +44 (0)1491 68073 Fax: +44 (0)1491 60762 E-mail: sales@sugatsune.co.uk Website: www.sugatsune.co.uk

SUGATSUNE AMERICA, INC.

Phone: +1 310 3296373 Fax: +1 310 3290819 E-mail: sales@sugatsune.com Website: www.sugatsune.com

SUGATSUNE SHANGHAI CO., LTD.

Phone: +86 (0)21 3632 1858 Fax: +86 (0)21 3632 1868 E-mail: lamp@sugatsune.com.cn Website: www.sugatsune.com.cn